




Shear Grab Parts List





RSG – Shear Grabs

Part No						
Model	3.8	4.4	5.0	5.8	Description	Qty
1	RSG3801	RSG4401	RSG5001	RSG5801	Body	1
2	RSG3802	RSG4402	RSG5002	RSG5802	Head	1
3	RSG3803	RSG4403	RSG5003	RSG5803	Cranked Tine	6/7/9/10
4	RSG3804	RSG4404	RSG5004	RSG5804	Nut	6/7/9/10
5	RSG3805	RSG4405	RSG5005	RSG5805	Straight Tine	2
6	RSG3806	RSG4406	RSG5006	RSG5806	Nut	2
7	RSG3807	RSG4407	RSG5007	RSG5807	Main Pin	2
8	RSG3808	RSG4408	RSG5008	RSG5808	Bush	2
9	RSG3809	RSG4409	RSG5009	RSG5809	Bolt	2
10	RSG3810	RSG4410	RSG5010	RSG5810	Nut	2
11	RSG3811	RSG4411	RSG5011	RSG5811	Grease Nipple	2
12	RSG3812	RSG4412	RSG5012	RSG5812	Pin	2
13	RSG3813	RSG4413	RSG5013	RSG5813	Pin	2
14	RSG3814	RSG4414	RSG5014	RSG5814	Bolt	4
15	RSG3815	RSG4415	RSG5015	RSG5815	Nut	4
16	RSG3816	RSG4416	RSG5016	RSG5816	Grease Nipple	4
17L	RSG3817L	RSG4417L	RSG5017L	RSG5817L	Corner Blade (Left)	1
17R	RSG3817R	RSG4417R	RSG5017R	RSG5817R	Corner Blade (Right)	1
18	RSG3818	RSG4418	RSG5018	RSG5818	Blade (Middle)	4/5/6/7
19L	RSG3819L	RSG4419L	RSG5019L	RSG5819L	Heel Blade (Left)	1
19R	RSG3819R	RSG4419R	RSG5019R	RSG5819R	Heel Blade (Right)	1
20L	RSG3820L	RSG4420L	RSG5020L	RSG5820L	Side Blade (Left)	1
20R	RSG3820R	RSG4420R	RSG5020R	RSG5820R	Side Blade (Right)	1
21	RSG3821	RSG4421	RSG5021	RSG5821	Bottom Barrel	1
22	RSG3822	RSG4422	RSG5022	RSG5822	Cylinder Hose	4
23	RHK1-2				Hose Kit (M & F)	1